



IDEAL NETWORKS

NavITEK NT/II

Upgrade Instruction



NavITEK NT/II (Basic) Software Release Notes Brief

Summary:

Release v1.0.11 replaces the previous production release (v1.0.10) for all previous versions of NavITEK NT or NavITEK II units

Main changes:

- New functionality
 - None

- Bug fixes
 - Unstable IP address gaining in DHCP mode and failure of Ping and TraceRoute in IPv4 & IPv6 over long run (>40min) of the tester.

For details please refer to full release note of NavITEK NT/II (Basic) via IDEAL Networks' sales representatives.

NaviTEK NT/II (Basic) Software Update Procedure

To update units with serial numbers starting with 153 (NaviTEK NT/II) to the current software version (v1.0.11 onwards):

1. Copy the file NaviTEK2.bin to a USB memory key
2. Ensure that the tester is connected to the mains power supply or that the battery is fully charged
3. Switch the tester ON
4. Insert the USB memory key into the tester
5. From the HOME screen, select F1 (SETUP) / SYSTEM / UPDATE
6. Select F1 (UPDATE)
7. Wait for the update to be completed
8. To check current installed version go to F1 (SETUP) / SYSTEM / ABOUT

To update units with serial numbers starting with 151 (NaviTEK NT/II PLUS & PRO) to the current software version please refer to NaviTEK NT/II PLUS & PRO upgrade instructions.



IDEAL NETWORKS

IDEAL INDUSTRIES LIMITED
Stokenchurch House, Oxford Road, Stokenchurch,
High Wycombe, Bucks, HP14 3SX, UK.

www.idealnetworks.net

A subsidiary of IDEAL INDUSTRIES INC.

